Service Manual of the YONGNUO Wireless Flash Guidance Device

YN-04II

I. Installation instruction

A. Launcher

1. Open the battery cover of the launcher;
2. Insert the battery (23A 12V) according to the (+/-) mark within the battery cap correctly and close battery the cover.

B. Receiver

1. Open the battery cover of the receiver;

2. Insert the battery (CR2) according to the (+/-) mark within the battery cap and close the battery cover.

II. Application method

A. Common method

1. Insert the flash lamp into the hot shoe of the receiver and press the button on the receiver. When the indication lamp of the receiver flashes, it indicates that it has started up. The indication lamp will flash once every 3s under normal circumstance.
2. Set the launcher and receiver in the same channel, start the power of the flash lamp and set up the output brightness of the flash lamp, then press the measurement button on the launcher, if the flash lamp flashes, it indicates that the product is under normal operation.
3. Insert the launcher into the hot shoe of the camera, at that time you can utilize the camera to point to the landscape to be shot and then press the shutter, the flash lamp on the receiver will flash under the synchronous signal of the launcher and then the picture required is achieved.

B. Special method

On the basis of che common mechod, another flash lamp can be inserted into the hot shoe which is build in YN-04 launcher. During shooting, the flash lamp on top machine launcher as well as on the receiver will flash synchronously according to the shutter of the camera, reaching an excellent flash fill effect.

C. Flash guidance of the film making lamp

On the basis of the common application method, you can also use the given connection wire to connect the film making lamp with the synchronous end of the receiver. During shooting, the film making lamp will flash under the synchronous signal as well.

D. Application of the multi-lamp

You can purchase several YN-04 receivers to connect with various flash lamps respectively and to be put in different places and angles, then insert the launcher into the hot shoe of the camera, at this time, all the flash lamps will flash under the synchronous signal of the camera, reaching the effect that several lamps will guide the flash.

III. Points for attention

1. When utilizing YN-04, the channel of the launcher and the receiver must be the same.
2. If the flash guidance distance can not reach the need for normal application, please inspect whether the battery quantity of the different parts is sufficient and then ensure whether the signal interrupt of the shooting environment you stay is too serious.

IV. Specification

Wireless band	ASK is adopted and there are 4 channels to be set by the user
Output terminal	Hot shoe of the receiver, synchronous end and hot shoe of the launcher
Synchronous speed	1/250 seconds
Remote distance	15-30meters
Application time of the launcher	More than 1000 times
Standby time of the receiver	More than 100 hours
Launcher power	23A 12V
Receiver power	CR2

This document was created with Win2PDF available at http://www.daneprairie.com.
The unregistered version of Win2PDF is for evaluation or non-commercial use only.